HIGOLD®

Top-Mount Sink Installation Instructions

www.HigoldHardware.com.au
Email: service@higoldhardware.com.au

Follow these instructions if you are **top-mounting** your HIGOLD sink into a bench.

NOTE - All HIGOLD top-mount sink installations use these instructions. Therefore, images may differ from your sink model. Ensure your sink is in perfect condition before installation.

Installation Components

	Description	Quantity
A	Composite sink	1
B	Box of installation anchor clips	1

Step 1 - Prepare benchtop

A template is provided or you can create one



Measure sink from edge to edge in mm



Cut hole in benchtop

Step 2 - Apply adhesive sealant

Clean around the edge of the benchtop sink hole and sink rim. Apply adhesive sealant to the underside of the sink rim. (Ensure that the sink edges are completely dry before applying the adhesive sealant)



Apply adhesive sealant

Step 3 - Affix sink

Insert sink into the bench hole and wipe away any excess adhesive sealant around the sink rim.



Insert sink in the bench hole

HIGOLD®

Under-Mount Sink Installation Instructions

www.HigoldHardware.com.au
Email: service@higoldhardware.com.au

Follow these instructions if you are **under-mounting** your HIGOLD sink into a bench.

NOTE - All HIGOLD under-mount sink installations use these instructions. Therefore, images may differ from your sink model. Ensure your sink is in perfect condition before installation.

Installation Components

	Description	Quantity
A	Composite sink	1
B	Box of hole plugs, anchor clips and bolts	1

Step 1 - Prepare benchtop

A template is provided or you can create one



Cut hole in benchtop as shown above. Match bench hole corner style to the sink, i.e. round corners for cornered sink

Step 2 - Prepare mounting clips

Apply adhesive sealant to the clip plate and paste the clip plate underneath the benchtop



Step 3 - Affix sink under bench

Position sink under the bench in line with the hole and then fasten the clip screw



Undermount with faucet hole on countertop



Undermount without faucet hole on countertop (Provide a gap between the sink and bench to accomodate the tapholes)

HIGOLD®

Composite Sink

www.HigoldHardware.com.au
Email: service@higoldhardware.com.au

Installing the Strainer

Your strainer should be installed by a licensed plumber. Use the screw to tighten the main body (from underneath the sink) and the stainless steel strainer (from above the sink) into place. Sealants are not required. Install the basket on top of the strainer.

Stainless steel basket
Removable for cleaning and general use

Fixing screw

Stainless steel strainer
Insert in rubber seal

Rubber seal
Insert this into sink hole

Rubber gasket
Inserts in main drain body

Main drain body
Installed underneath sink hole
Plumber connects into plumbed drain

Care Instructions

HIGOLD composite sinks are made from a HIGOLD patented recipe that comes with multiple advantages. HIGOLD granite composite sinks are extremely durable and scratch resistant.

Cleaning

- Clean the sink regularly with soapy warm water. Always rinse the sink after using cleaning products.
- Avoid solvents, alcohol, bleaching or acidic products, harsh chemicals and abrasives (cleaners and steel wool products) as they may irreparably damage the product surface.
- Wipe the surface of the sink with a gentle cloth to remove liquid residue.
- Regularly clean the drain to prevent clogs and odors.

Care

- Do not cut food directly on the surface.
- Some foods after prolonged periods can damage the surface: e.g. foods and juices that contain acid or vinegar

Limited Lifetime Warranty

HIGOLD is a brand authorized to Vanguard Design Group Pty Ltd (ABN 48 104 411 314). It offers a limited Lifetime warranty on all its composite sinks, guaranteeing that they are free from material and manufacturing defects.

HIGOLD will repair or provide a replacement, may be free of charge depending on its discretion, for any HIGOLD composite sink that presents defects under normal domestic residential use. Associated accessories and strainers have a standard 12 month warranty.

This warranty is valid for the original purchaser only, as long as the product has been handled with care, installed and maintained as per the instructions given. To make a claim, a report must be sent to HIGOLD within 10 business days upon discovering the defect. This warranty will be voided if the product is used in a commercial setting or for a purpose in which it is not designed for.

Normal wear and tear, damage, incorrect installation, misuse, or modification will not be covered under this warranty. Scratches, stains, and damages are consequences of use and not defects covered by this warranty.

This is a summary of the full warranty terms and limitations and claim processes at www.HigoldHardware.com.au/warranty-terms/.